

TU-KOY TOOL CLAMP

ITEM: C4525

Our cone disassemblers supports are manufactured with the utmost care to preserve the optimal conditions of your toolholders.

The characteristics of the supports avoids possible contact between the cone and support thanks to the shape and the presence of an O-ring.

Keep clean all surfaces to always ensure maximum performance.

The good condition of the cone will always ensure exact setting and precise machining.

HANDY**HANDY40****HANDY50****HANDY63**

Rotation - positioning

1. Pull the indexing knob to unlock
2. Turn into a new position at 0° 90° or 180°
3. Release the knob to block

Toolholders blocking

1. Insert holder making sure the cone is perfectly clean
2. Check the correct positioning into centering dowel
3. Rotate locking knob toward SK or BT according to cone version

Toolholders extraction

1. Rotate locking knob to central positioning
2. Extract holder

Tech. Code		Coupling	A mm	B mm	C mm	D mm	E mm	F mm	G mm	Base mm	Weight Kg
C4525SK40		SK40 - BT40	121	97	29	12	122	60	50	110 x 110	5,0
C4525SK50		SK50 - BT50	152	128			172	89	71	130 x 130	12,5
C4525HSK63		HSK63	124	101			122	60	50	110 x 110	5,2