



The location has to be milled to allow for the correct positionning and prevent the chucking spigot "F/A" (automatic) from twisting.

Ensure that the positioning device is attached in a manner that aligns the pallet or jig according to your specifications when placed in the Robot magazine. The "F/A" chucking spigot can be positioned at intervals of 90°.

Eight supporting feet increase the tilting stability of the pallets and jigs by 30 %

90

90

5

NBM.ACTR



